


To Change the magnification with the Pan & Zoom Window tool.

Choose View > Zoom > Pan & Zoom, or click the Pan & Zoom tool in the Select and Zoom toolbar.

Do any of the following: Drag the handles of the box in the Pan & Zoom window to change the document magnification



This map is a graphic representation prepared by
The City of Weatherford, Technical Services
GIS Department and intended for use only as a reference.
Data depicted here is not guaranteed for accuracy and
may be subject to revision at anytime without notification.
Not a Certified Drawing
Not for Design



Schedule

	Monday / Thursday
	Tuesday / Friday